



Wood Filler

- Water based
- Easy to use
- Drying time 1 hour minimum
- Low odour
- Flexible and stainable
- Minimal shrinkage
- Suitable for interior and exterior use
- Wide range of colours available



Product use

Liberon Wood Filler is a water based, multi-purpose filler used to fill and repair surface damage in wood. Quick drying, shrink and crack resistant, flexible and stainable, it is easily sanded and may be screwed and nailed. The low odour, easy to use Wood Filler is suitable for both interior and exterior use. Wood filler may be stained, varnished, waxed or painted. When using outdoors protect with a suitable exterior grade finish. Wood Filler is available in natural and a selection of wood shades, it may also be coloured with Liberon Earth Pigments.

Preparation

Ensure the area to be repaired is clean, dry and free from dust. Select the colour which is closest to the colour of the wood, adapting your choice if dying the wood.

Application

Apply using a Liberon plastic scraper or suitable filling knife. For best results resist overspreading the repair area, but leave sufficient over fill to enable thorough sanding. Allow to dry thoroughly – two hours or more depending on the depth of the repair. Then sand, colour and finish as required.

Small holes may be filled in one operation. Deeper holes should be built up in layers.

Important: always test products first on an inconspicuous area to check colour, compatibility and end results. Wood Filler may accept dyes/stains differently to surrounding wood.

Packaging

Wood Filler is available in 25 ml BP and 125 ml containers.

Colours

Natural, Antique Pine, Dark Oak, Mahogany.

Health and Safety

The use of gloves is recommended when applying this product. Do not apply below 10°C and store frost-free. Keep out of the reach of children.